



# Model Rocket RMS™ O-ring, Spacer & Insulator Guide


## 18/20 Model Rocket RMS



Aft O-ring  
5/8" x 1/16" 014




Forward O-ring  
5/8" x 3/32" 111



Aft O-ring  
7/8" x 3/32" 115


## 24/40 Model Rocket RMS



Forward O-ring  
7/8" x 1/16" 018




Delay O-ring  
5/8" x 3/32" 111




Forward Insulator


## 24/60 Model Rocket RMS



Forward & Aft O-rings  
13/16" x 1/16" 017




Delay O-ring  
5/8" x 3/32" 111




Forward Insulator

## 24/20-40 Model Rocket RMS-R/C




Aft O-ring  
7/8" x 3/32" 115




Forward Insulator  
(E12-RCJ Only)


## 29/40-120 Model Rocket RMS



Forward & Aft O-rings  
1" x 1/16" 020




Delay O-ring  
5/8" x 3/32" 111




Forward Insulator

## 32/60-100 Model Rocket RMS-R/C



Aft O-ring  
1-1/8" x 1/8" 212



Forward Insulator  
(F16-RCJ Only)